

## HP Service Mode PIN #'s Reference Chart

HP LaserJet	Service Mode Pin #
2300	11230002
2410	10241004
2420	10242004
2430	10243004
4100 MFP	04410002
4101 MFP	04410002
4200	11420002
4240	04424005
4250	09425004
4300	11430002
4345 MFP	11434504
4350	09435004
5200	05520006
9000	00900001
9000 MFP	00900001
9040	04904005
9040 MFP	11904004
9050	09905004
9050 MFP	11905004
9500	04950003
M3027	11303506
M3035	11303506
M4345 MFP	11434506
M4555 MFP	04455511
M5025	11502506
M5035	11503506
M601	10060311
M602	10060311
M603	10060311
M9040	04904008
M9050	04905008
M9059	04905008
P3005	10300506
P3015	07301509
P4014	05401408
P4015	05401508
P4515	05451508

HP Color LaserJet	Service Mode Pin #
3000	11300005
3500	10350003
3550	10350003
3600	11360005
3700	10370003
3800	11380005
4600	04460002
4610	05465004
4650	05465004
4700	09470005
4730 MFP	09473005
5500	04550002
5550	09555004
9500	04950003
9500 MFP	11950004
CM6030	04603008
CM6040	04604008
CM8050	704938
CM8060	704938
CP3505	06350507
CP3525	09352508
CP3530	11353008
CP4005	10400506
CP4025	11402509
CP4525	11452509
CP4349	11434506
CP4540	11454010
CP5525	11552010
CP6015	03601508
M4730	05473007
M525	05052512
M551	09055111
M575	05057512

Reference chart provided by KB Printer and Computer Support

All rights reserved.

[www.kbpcsupport.com](http://www.kbpcsupport.com)